

Fastening material

best wood **Screw-in anchor H for insulation boards**

Screw Ø 6 mm to fasten insulation board WALL 140/180 and pre-plastered WALL 140/180 in timber frame constructions and solid wooden substrates.

A fastening on mineral substrates should not be carried out. For the **pre-plastered WALL 140/180**, the screw-in plate of about the thickness of the plaster layer has to be inserted. This fastening system should only be used for board installations that are carried out as one single layer.

Screw-in plate Ø 35 mm. Effective screw-in depth: 35 mm

Screw length = thickness of insulation board + 20 mm

The pre-plastered WALL 140/180 is only available in the dimension of 60-160 mm.

Currently in the ETICS approval process.



Screw-in anchor H for insulation boards
not preassembled

Item no.	Delivery form	PU	UP	
6112DSH6/80	Anchor length 80 mm	100 pc/pack	pack	
6112DSH6/100	Anchor length 100 mm	100 pc/pack	pack	
6112DSH6/120	Anchor length 120 mm	100 pc/pack	pack	
6112DSH6/140	Anchor length 140 mm	100 pc/pack	pack	
6112DSH6/160	Anchor length 160 mm	100 pc/pack	pack	
6112DSH6/180	Anchor length 180 mm	100 pc/pack	pack	
6112DSH6/200	Anchor length 200 mm	100 pc/pack	pack	
6112DSH6/220	Anchor length 220 mm	100 pc/pack	pack	
Polystyrene caps (EPS) are already included in the packing unit				

Only available in full packing units (packs)